



TV·EARS®

Dr. Recommended TV Listening Devices

TV Ears Voice Cord Instructions



Power Microphone




Voice Cord




Extender Cord



Insert Power Microphone plug into the Voice Cord jack



Insert voice cord plug into the "Accessory" jack on your headset



Velcro the Power Microphone to the Voice Cord by removing the thin protective covering on the Power Microphone



Add more length to your audio cord using your Extender Cord.

Simply connect the Extender Cord between the Power Microphone and Voice Cord.

Battery Replacement

To replace your battery follow the directions below:



The voice cord is the small black box and requires only **ONE 'AA' battery**

To place battery into battery pack, remove the screw with a small Phillips head screwdriver



Place the 'AA' battery into the empty slot marked **UM 3x2** in the battery pack